

Surface Planer

NEVER run used wood through this machine: only **NEW SOLID WOOD** can be used.

Get approval of Shop Technician before operating.

Allow machine to feed stock.

NEVER push or pull material through machine.

If stock binds or stops, adjust depth to allow completion of the cutting pass.



COMPOSITES PLANER

Shut off the machine if stock fails to feed all the way through.

NEVER look or reach into the mouth of the machine while it's running.

Plane only with the grain of the wood.

The maximum depth of cut per pass should not exceed 1/16th inch.

The stock **MUST** be at least 12 inches long.

Keep hands away from the cutterhead.

The old surface planer may be used to thickness composite materials such as: Homasote, MDF and particle board.

SOLID WOOD PLANER

